

Evaporator Fan Not Working

Step 1
Unscrew the back cover.



Step 2
Check the connecting wire of fan to see if the terminals are loose. Better to disconnect and then connect again.



Step 3
If the connecting wire and terminals are fixed, please unscrew the fan cover inside the cabinet.



Step 4
Check if the fan plate can spin well and the connecting wire and terminals are fixed. Better to disconnect and then connect again.



Step 5
Power on the fridge, change the fan if it's still unworkable.